

DKW SHOCK ABSORBER DETAILS

<u>Application</u>	<u>Chassis No.</u>		<u>DKW</u>	<u>Boge</u>	<u>Dimensions</u>
	<u>From</u>	<u>To</u>	<u>Part No.</u>	<u>Part No.</u>	<u>Closed / Open</u>
Front Shocks					
All except Sp thru 1958	-----	588302	6803-22450-10 25-7009-22450-00	TP 27 337 TP 27 349E	
All exc. Sp 1959 - 1960 For tropics, export & sport	588303	-----	6803-22450-22 6803-22450-03-120	ATP 32-288(-1 & -2) ATP 32-343/2	12 3/8" - 16"
All exc. SP and Universal from 1962 on (Note 1) For tropics, export & sport (Note 1)	-----	-----	6815-04042-02 6820-04070-01	ATP 32-3391 ATP 32-366-1	
Universal from 1962 (Note 2)	-----	-----	6822-04070-00	ATP 32-463	
AU 1000Sp	-----	004160	6815-04070-02 or 6815-04042-02 (previous part no.)	ATP 32-339	
AU 1000Sp	004161	-----	6822-04070-00	ATP 32-463 (Note 3)	
Rear Shocks					
All except Sp thru 1958	-----	588302	6803-24150-10 25-7009-24150-00	TP 27-328 TP 27-350E	11 7/8" – 16 5/8"
All exc. Sp 1959 - 1960 For tropics, export & sport (Note 4) (Note 5)	588303	-----	6803-24150-21 6803-24150-00-120 6001-04071-05	ATP 32-289 ATP 32-344 TTP 32-367-1	11 3/4" - 16 1/2"

DKW SHOCK ABSORBER DETAILS

<u>Application</u>	<u>Chassis No.</u>		<u>DKW</u>	<u>Boge</u>	<u>Dimensions</u>
	<u>From</u>	<u>To</u>	<u>Part No.</u>	<u>Part No.</u>	<u>Closed / Open</u>
All exc. SP and Universal from 1962 on (Note 6)	-----	-----	6820-04071-02	ATP 32-449	
For tropics, export & sport (Note 6)			6820-04071-01	TTP 32-367-2	
Universal from 1962	-----	-----	6803-24150-21	ATP 32-289	
AU 1000Sp	-----	004160	6815-04062-01	ATP 32-336	
AU 1000Sp	004161	-----	6820-04071-02	ATP 32-449	

Notes:

- 1) Can also be fitted to front of all pre 1962 AU 1000 cars.
- 2) Can also be fitted to front of pre 1962 Universals.
- 3) Same shock as fitted to front of Universal 1962 on.
- 4) Rear of pre 1960 models.
- 5) For 1960 models. Can also be fitted to rear of pre1960 models.
- 6) Can also be fitted to rear of all pre 1962 AU 1000 cars.